







1






2




WH-XB700









Android™ iPhone



3





?

http://rd1.sony.net/help/mdr/whxb700/h_zz/